

MNB Series 032, 040, 050 063, 080, 0100



Construction



* The numbers correspond with those in the "Construction" of the MNB series in the Web Catalog.



* Replaceable with the rod boot assembly For details on replacement part numbers, refer to page 245.

Seal Kit List

No.	Description	Material	Note	
38	Piston seal			
39	Cylinder tube gasket	NBR		
40	Rod seal A	INDH		
41)	Cushion seal]		

Replacement Parts: Seal Kit

riopiacomonici artor coarren					
Bore size (mm)	Part no.	Contents			
32	MB32Z-PS				
40	MB1-40Z-PS				
50	MB1-50Z-PS	Set of nos.			
63	MB1-63Z-PS	38, 39, 40, 41			
80	MB1-80Z-PS				
100	MB1-100Z-PS				


* Since the lock section for the MNB series is normally replaced as a unit, kits are for the cylinder section only. These can be ordered using the order number for each bore size.

* The seal kit includes a grease pack (ø32 to ø50: 10 g, ø63 and ø80: 20 g, ø100: 30 g).


Order with one of the following part numbers when only the grease pack is required.

Grease pack part no.: GR-S-010 (10 g), GR-S-020 (20 g)

Replacement Parts: Lock Unit



G Port



Rotary Actuators Air Grippers

Control Equipment Modular F.R.L.

Air Preparation Equipment

Industrial Filters

Replacement Procedure

Actuators

Rotary Actuators Air Grippers

Pressure Control Equipment

Preparation Equipment